

#### **S**36





35 6

10 Ø

3 Ø hole

12 Ø

### **Button**

scale: full size

## **Spinner** (section)

scale: full size

### Toggle (x2)

scale: full size



# **BUTTON & STRING SPINNER**

## HOW TO USE THE BUTTON AND STRING SPINNER

Thread the string through the holes in the button and toggles as shown in the picture .

Hold the toggles, one in each hand. With the button in the middle of the string, swing the button in a circle so that the string forms a braid on each side of the button. Then rhythmically tighten and relax the string by moving the hands away from and towards each other. Soon the button will respond to the rhythm and make a humming sound as it alternately spins one way and then the other.

Woodturners Association of Western Australia - Swan Woodturners Drawing Library - Drawing S36